



ARRIVAL

INSTRUCTIONS FOR AVOIDING ACCIDENTS

DEPARTURE



1. Driver reverses vehicle to the dock and disconnects the trailer from the towing vehicle.



4. Driver places cone in front of the load carrier.



1. Prohibited to connect the vehicle before loading/unloading has been completed.



4. Driver checks that the door on the dock is down and that the dock weather shelter is off.



2. Driver applies the parking brake.



5. Driver contacts the responsible person at the terminal to state that the vehicle has been parked and is ready for loading/unloading.



2. Terminal worker removes straps and closes the door on the dock.



3. Driver put chocks on the load carrier.



6. Terminal worker secures vehicle to the dock with straps.



3. The responsible person at the terminal informs the driver that the vehicle is ready for departure.



5. Driver prepares the vehicle for departure by:



Removing chocks.



Removing cone. The chocks and cone are placed in their designated places.



Connecting the vehicle.



Releasing the parking brake.